

G50 Instructions:

Battery Installation

- Turn the end cap in a counter-clockwise direction to remove the cap.
- Remove the battery cartridge.
- Place three AAA batteries into the cartridge in the direction indicated on the ends of the cartridge.
- Replace the cartridge in the light in the direction indicated by the arrow on the cartridge.
- Replace the tail cap and turn it clockwise to tighten it until it is fully closed.

On/Off Operation

- The G50 has a rear switch on the tail cap.
- To turn on the light, press the switch fully until it “clicks” then release.
- To turn off the light, press the switch fully until it “clicks” then release.

Pure Beam Focusing Optic

- This flashlight is equipped with COAST’s Pure Beam™ Focusing Optic that allows the user to choose between a broad flood beam and a focused Bulls-Eye Spot™ beam for long distance illumination.
- To adjust the beam into the Bulls-Eye Spot™ mode, turn the front bezel of the light clockwise.
- To adjust the beam into the broad, flood light mode, turn the front bezel of the light counter-clockwise.

Maintenance: Wipe the external body with a damp cloth. Do not submerge.